

Transponder Fitting Instructions

Step One

- Attach a small piece of Blu-Tack to the back of the transponder



Step Two

- Ensure your front fork is clean and dry
- Press the transponder onto the right front fork approximately 50mm from the bottom of the fork



Step 3

- Using the cable ties provided tie the transponder to your fork
- Be careful not to cable tie your spokes
- Trim the end of the cable ties



**Correctly Attached
Transponder**

